


## Warnings and Instructions: Review carefully, proper application is required


**⚠ Warning:** This device will not prevent or eliminate risk of injury. Do Not Overtighten. If swelling, pain, skin irritation, or an unusual reaction occurs, discontinue use immediately and consult your medical professional.

This device should not be worn by persons with known allergies to neoprene.

Care: Hand wash using mild soap. Rinse thoroughly. Air dry only. Do not tumble dry.




1. Disassemble the entire brace, removing:
  - A. The straps
  - B. The humerus and forearm cuffs
  - C. Remove the hinge from it's padded pocket




- 1D. If utilizing the ROM hinge, preset your prescribed range of motion and direction, and reinsert into the hinge pocket. If Standard or Heavy Hinge is being prescribed, check for prescribed directional movement and reinsert into the hinge pocket.



2. Encircle the humerus with its cuff. The condyle pad should be placed just lateral of the humeral condyle. (As designed, the point of the triangular condyle pad should be pointing upward.) Adjust for circumference. Trim if necessary for a custom fit.



3. Encircle the forearm cuff. Adjust for circumference. Trim if necessary for a custom fit.




4. Attach the velcro<sup>®</sup> straps (longer for humerus, shorter forearm) to the humerus and forearm cuffs, secure straps by encircling the arm.

## Warnings and Instructions: Review carefully, proper application is required


**⚠ Warning:** This device will not prevent or eliminate risk of injury. Do Not Overtighten. If swelling, pain, skin irritation, or an unusual reaction occurs, discontinue use immediately and consult your medical professional.

This device should not be worn by persons with known allergies to neoprene.

Care: Hand wash using mild soap. Rinse thoroughly. Air dry only. Do not tumble dry.




1. Disassemble the entire brace, removing:
  - A. The straps
  - B. The humerus and forearm cuffs
  - C. Remove the hinge from it's padded pocket



- 1D. If utilizing the ROM hinge, preset your prescribed range of motion and direction, and reinsert into the hinge pocket. If Standard or Heavy Hinge is being prescribed, check for prescribed directional movement and reinsert into the hinge pocket.



2. Encircle the humerus with its cuff. The condyle pad should be placed just lateral of the humeral condyle. (As designed, the point of the triangular condyle pad should be pointing upward.) Adjust for circumference. Trim if necessary for a custom fit.



3. Encircle the forearm cuff. Adjust for circumference. Trim if necessary for a custom fit.



4. Attach the velcro<sup>®</sup> straps (longer for humerus, shorter forearm) to the humerus and forearm cuffs, secure straps by encircling the arm.